

## PARTS LIST

Parts No.	Description	Number pcs required
1	Hexagon head screw	2
2	Hexagon nut	6
3	Washer	8
4	Floor stand (right)	4
5	Wheel assy (uptional)	1
6	Cotter pin	2
7	Square neck bolt	6
11	Hexagon head screw	15
12	Hexagon nut	12
14	Floor stand handle (optional)	1
15	Adjusting rod	1
16	Electric cord	1
17	Pivoting rod	1
18	Support plate	1
19	Stock stop	1
20	Hexagon socket headless screw	1
21	Stock stop rod	1
22	Wire relief retainer	1
23	Switch	1
24	Hexagon nut	1
26	Switch panel	1
27	Adjusting rod support	1
28	Hand wheel	1
30	Thrust washer	1
32	Lead screw	1
33	Vise nut	1
34	Movable vise plate	1
35	Washer	1
36	Hexagon head screw	1
37	Bed	1
39	Scale	1
40	Electric cord corver	1
43	Rubber ring	2
44	Electric cord	1
45	Nut plate	2
46	Spring adjusting screw	1
47	Spring	1
48	Screw	1
49	Mitering vise plate	1
50	Hexagon head screw	1
51	Washer	16

Parts No.	Description	Number pcs required
52	Hexagon head screw	4
53	Hexagon head screw	1
54	Pivot	1
55	Vertical cutting plate	1
56	Vertical cutting plate stand	1
57	Adjustable bracket (left)	1
58	Plum screw	1
59	Blade back safety cover	1
60	Thrust washer	4
61	Bearing	6
62	Guide pivot	4
63	Bearing shaft pin	2
64	Blade adjustable seat	2
65	Adjustable bracket (right)	1
66	Blade roller bearing guide adjustable lock	2
67	Spring washer	2
68	Screw	5
69	Blade guard	1
70	Hexagon nut	4
71	Blade wheel (front)	1
72	Blade wheel bearing cover	1
73	Key	5
75	Hexagon head screw	1
76	Switch cut off tip	1
77	Blade wheel(rear)	1
79	Blade tension adjustable knob	1
80	Spring	1
81	Body frame	1
83	Hexagon head screw	2
84	Motor mount plate	1
85	Motor	1
86	Motor pulley	1
87	Ball bearing	4
88	Bearing bushing	1
89	Oil seal	2
90	Transmission wheel shaft	1
91	Transmission gear	1
92	Gear box gasket	1
93	Gear box cover	1
94	Worm gear	2
96	Bearing bushing	1

Parts No.	Description	Number pcs required
98	Plum screw	1
99	Washer	1
100	Screw	6
101	Worm gear pulley	1
103	Blade tension sliding plate	1
104	Hexagon socket headless screw	2
105	Spring pin	1
106	Sliding plate draw block	1
107	Blade wheel shaft	1
108	Shaft block	1
109	Blade tension sliding guides	2
110	Motor pulley cover	1
112	Belt	1
113	Blade	2
114	Washer	2
117	Washer	1
118	Thrust washer	1
120	Bearing	1
121	Round head cross' socket screw	1
122	Hexagon nut	3
126	Bushing	1
131	Switch protection bracket	1
132	Blade safe guard	2
134	Screw	4
140	Hexagon nut	4
156	Round head cross socket screw	3
157	Star washer	1
158	Support plate	2
169	Cross socket screw	2
170	Tool plate	1
171	Rubber pad	4
174	Wheel stand	1
175	cotter pin	2
176	Axle	1

